

<section-header><section-header>

Contents

1.	Names of components	2
2.	Safety Devices	3
3.	Specifications	4
4.	Wiring Diagam	4
5.	Sequence Time Chart	5
6.	Troubleshooting	6
7.	Standard resistance & Voltage	13
8.	Check & Repair	15

Shizuoka Seiki Co., Ltd.

<u>2014.08</u>

1 Names of components



★ Burner Section



- 15 Insulating Board
- **16 Overheat Prevention System**
- 17 Fuse
- **18 Flame Monitor**
- 19 Fan Motor
- 20 Switch Section
- 2 Fuel Pump
- 22 Fuel Preheater
- 23 Solenoid Valve

★ Switch Section



- 23 Operating Switch This ignites or extinguishes the flame. (Refer to pages 9.)
- Change-over Switch This chages over combustion in two step.
- Operating Lamp This is lit while (the heater is) operating and cooling down.
- Misfire Lamp This is lit when the flame is extinguished irregularly.
- ② External Thermostat Connector

2 Safety Devices

Description of Safety Devices					
() Tip-over Switch	Automatically extinguishes the flame when motion or an impact is detected during operation. Operating condition : The misfire lamp lights and if the heater is operating, the fan will cool down the heater for about 3 minutes (hereafter referred to as post purge).				
(6) Overheat Preven- tion System	Automatically extinguishes the flame should the heater overheat. Operating condition : The misfire lamp lights and if the heater is operating, the fan will cool down the heater for about 3 minutes (hereafter referred to as post purge).				
ID Electrical SystemProtection (Fuse)	Cuts off power to the heater should an electrical surge pass through the circuit caused by damage to the heater, etc. Operating condition : The whole operation stops.				
(8) Flame Monitor	This automatically extinguishes the flame when ignition fails or flame goes out during the operation. This monitor, when it detects any irregularity before ignition, automatically extinguishes the flame. Operating condition : The misfire lamp lights and if the heater is operating, the fan will cool down the heater for about 3 minutes (hereafter referred to as post purge).				
22 Fuel Preheater	This fuel preheater warms the fuel up to prevent its viscosity from rising. This starts to oper- ate at the time of plugged-in if the ambient temperature is below 5°C (41°F).				
Anomaly detection system for fan motor	This automatically extinguishes the flame when some errors are detected in fan motor such as cable disconnection.				

When the flame is extinguished, turn **[OFF]** the operating switch. Then turn **[ON]** the operating switch again after the problem is solved.

3 Specifications

Model Type	9	VAL6MPX5	VAL6MPX1		
Туре		Radiated/Direct-fired			
Ignition System	1	High intensi	ty discharge		
Fuel		#1DIESEL(H	(EROSENE)		
Fuel Consumptio	n	High : 0.48GAL/h , 1.55kg/h	High : 1.8L/h , 1.55kg/h		
	ות	Low : 0.42GAL/h , 1.38kg/h	Low : 1.6L/h , 1.38kg/h		
Heat Output		High : 62,500BTU , 18kW	High : 15,800kcal/h , 18kW		
		Low : 55,500BTU , 16kW	Low : 14,000kcal/h , 16kW		
Tank Capacity		6.6 gallons	25liter		
Continuous Operatin	n Timo	High : 1	3.7hours		
Continuous Operating Time		Low : 15	5.7hours		
Dimensions	inch	28.4(H)×20.5	5(W)×26.6(D)		
Dimensions	mm	720(H)×520(W)×675(D)			
Dry Weight		70.5Lbs , 32kg			
Power Supply		AC120V 60Hz	AC230V 50Hz		
Power Concumpt	ion	When ignitiong : 100W	When ignitiong : 100W		
		When burning : 120W	When burning : 112W		
Electric Fuse		3A 1.6A			
Operating Noice I	ovol	High : 59.4dB			
Operating Noise L	evei	Low :	57.8dB		
Airflow		110	CFM		
		Tip-ove	r Switch		
		Flame	Monitor		
Safety Systems	6	Electrical Syst	em Protection		
		Overheat	Prevention		
		Anomaly detection system for fan motor			
		No:	zzle		
Accessory		Filter E	lement		
		Nozzle	Wrench		

4 Wiring Diagram



5 Sequence Time Chart



<u>
 <u>*</u>Fuel pre-heater : Operating when the temperature in the inside of burner cover falls below 41 degrees Fahrenheit (5 degrees Celsius) and stopping when it reach over 68 degrees Fahrenheit (20 degrees Celsius).
</u>

6 Troubleshooting

Phenomenon

page

	The lamp does not light on			
The heater does not start	Operation lamp is lit			
	Misfire lamp is lit	-		
	Fuel pump does not operate at all			
The heater does not ignite	No fuel or a little fuel is pumped up	8		
(though the heater is working)	Igniter does not spark. [Igniter does not operate]			
	Sequence of operation is normal, but it doesn't ignite			
Misfire within 10 seconds after ignition	Misfire lamp is lit	9		
Combustion stop during the operation	Misfire lamp is lit	10		
Odor comes out				
Smoke comes out				
Combustion is not stable		11		
Fuel leaks				
	When the plug is put into the socket			
Fuse blows out	When the switch is turned on	12		
About 5 seconds after turning on				
	The heater does not start The heater does not ignite (though the heater is working) Misfire within 10 seconds after ignition Combustion stop during the operation Odor comes out Smoke comes out Combustion is not stable Fuel leaks Fuse blows out	The heater does not startThe lamp does not light on Operation lamp is lit Misfire lamp is litThe heater does not ignite (though the heater is working)Fuel pump does not operate at all No fuel or a little fuel is pumped up Igniter does not spark. [Igniter does not operate] Sequence of operation is normal, but it doesn't igniteMisfire within 10 seconds after ignitionMisfire lamp is lit Odor comes outOdor comes outMisfire lamp is litSmoke comes outMisfire lamp is litFuel leaksFuel leaksFuse blows outWhen the plug is put into the socketWhen the switch is turned on About 5 seconds after turning on		

Phenomenon		Possible Cause	How to check	Result	Remedy
1. The heater does	The lamp does not	No power source supplied	Measure voltage of AC outlet.	If circuit tester indicates 0V, power	Connect power source
not start. light on.			Standard: MPX5 - AC120V MPX1 - AC230V	source is disconnected	
		Fuse blowout	Take fuse out from fuse box, and then check each lead with circuit tester	If multimeter reads $\infty \Omega$, fuse blows out	Find a cause of blown fuse and replace with a new one
		Disconnection of power cable	Take power source connector (CN 1)	If either of the lead is broken, power	Make sure the power cable is
			out from burner controller, and then check each lead with multimeter	cable is broken	connected, or replace it
		Loose connection of power source connector	Plug in power source connector (CN 1) again, and then turn on	If it works normally, power source connector fails in contact	Plug in connector (CN 1) firmly
		Loose connection of transformer connector	Plug in transformer connector (CN 7) again, and then turn on	If it works normally, transformer connector fails in contact	Plug in connector (CN 7) firmly
		Failure of transformer	Measure voltage at output side of transformer connector (CN 7) Standard (purple-purple):	If multimeter reads normal voltage at input side, and reads 0V at output side, transformer fails	Replace transformer
		T	about AC15V		
		switch connector	(CN 8) again, and then turn on	If it works normally, operation switch connector fails in contact	Plug in connector (CN 8) firmly
		Failure of operating switch	Take operating switch connector (CN 8) out, and then check lead with Standard: Conducting (0Ω) when	If it doesn't conduct when turned on, operating switch fails	Replace operating switch
		Failure of burner controller	Measure voltage at input side of transformer connector (CN 7) Standard (white-red): MPX5 - AC120V MPX1 - AC230V	If power source is normal and multimeter reads 0V at input side, burner controller fails	Replace burner controller
Run lamp is lit		Loose connection between thermostat connector and cap	Attach the cap firmly	If it works normally, the cap fails in contact with thermostat connector	Attach the cap firmly
	Misfire lamp is lit.	Flame monitor lens is perplexed by direct sunlight	Unplug flame monitor connector (CN 11), and then start operation	It starts to operate	Avoid direct sunlight on radiation disk
		Failure of burner controller		It doesn't start to operate	Replace burner controller

Phenomenon		Possible Cause	How to check	Result	Remedy
2. The heater does not ignite.	Fuel pump does not operate at all.	Loose connection of fuel pump connector	Plug in fuel pump connector (CN 6) again, and then turn on	If it works normally, fuel pump connector fails in contact	Plug in connector (CN 6) firmly
		Loose connection of joint connectors in fuel pump	Plug in joint connectors in fuel pump again, and then turn on	If it works normally, connectors on fuel pump fails in contact	Plug in Joint connectors firmly
		Failure of fuel pump	Measure voltage at output side of fuel pump connector on burner controller	If voltage is normal, fuel pump fails	Replace fuel pump
		Failure of burner controller	Standard (blue-blue) MPX5 - AC60~96V MPX1 - AC 115~184V	If multimeter reads 0V, burner controller fails	Replace burner controller
	No fuel or a little fuel is pumped up.	Fuel line is clogged	Disconnect each fuel line, and then clean up each of them	If it ignites after cleaning, fuel flow decreases because of clogged in fuel lines	•Clean fuel lines •Clean and rinse the fuel tank with kerosene, alcohol or acetone
		Filter element is clogged	Check clarity of filter element	If filter is dirty, fuel flow decreases because of clogged filter element	•Replace filter element •Clean and rinse the tank with kerosene, alcohol or acetone
		Nozzle is clogged	Replace nozzle	If it ignites, nozzle is clogged	 Replace nozzle Clean and rinse the fuel tank with kerosene, alcohol or acetone
		Loose joint in fuel lines	Check looseness of each joint	If heater ignites by joints fastened more tightly, air is absorbed into fuel lines at loosed joints	Fasten joints more tightly
		Fuel pump is clogged, or failure	Remove burner cover and fuel outlet line, and then turn on the switch	No fuel is pumped up, fuel pump is clogged or failure	Replace fuel pump
		Failure of burner controller	Measure voltage at fuel pump connector on burner controller standard (blue-blue) MPX5 - AC60~96V MPX1 - AC115~184V	If multimeter reads power supply voltage , burner controller fails	Replace burner controller
	Igniter does not spark.	Loose connection of igniter connector	Plug in igniter connector (CN 4) again, and then turn on the operating switch	If it works normally, loose connection of igniter connector	Plug in connector (CN 4) firmly
	[Igniter does not operate.]	Failure of igniter	Measure voltage at igniter connector (CN4) on burner controller Standard (black-black):	If voltage is normal, igniter fails	Replace igniter
		Failure of burner controller	MPX5 - AC120V MPX1 - AC230V	If multimeter reads 0V, burner control fails	Replace burner controller
	Sequence of operation is normal,	Alignment of electrode is out of standard	Measure the alignment of electrode	If any part is out of standard position, out of alignment is cause	Replace electrode (adjust the position)
	but it doesn't ignite	Improper quantity of combustion air	Check gate opening of fan motor	If gate opening is unusual, quantity of combustion air is improper	Adjust gate opening. Normal scale: MPX5 - 2.5

Phenomenon		Possible Cause	How to check	Result	Remedy
3. Misfire within 10	Misfire lamp is lit.	Loose flame monitor	Open burner cover, and check if the	If flame monitor comes off, it	Put in flame monitor firmly
seconds after ignition	-		flame monitor is in	doesn't work	
seconds uncer ignition.		Shortage of light sensed from	Take flame monitor out, and then	If lens of flame monitor is dirty less	Wipe lens of flame monitor with
		flame	check clarity of its lens	sensitive.	soft cloth
			Remove burner, and then check clarity	If burner cone or fan is dirty, it	Clean burner cone and whirl vane
			of burner cone and vane	senses little light	
			Check extent of combustion air inlet	If opening is too extensive, flame is	Decrease opening to reduce
			opening	short because combustion air is too	combustion air.
				much	Normal scale:
					MPX5 - 2.5
					MPX1 - 4.5
		Loose connection of flame	Plug flame monitor connector (CN	If it works normally, flame monitor	Plug connector (CN 11) firmly
		monitor	11) again, and then turn on	connector fails on contact	-
		Failure of flame monitor	Measure voltage at flame monitor	If voltage doesn't change, flame	Replace flame monitor
			connector on burner controller	monitor fails	-
			standard		
			dark - about DC5V		
			light - DC1.2V and under		
		Namela ala ana d	 Dll-		Deulees north
		Nozzie clogged	kepiace nozzie	II It ignited, nozzle is clogged	Kepiace nozzie
		Filter element clogged	Check clarity of filter element	If filter is dirty, fuel flow decreases	Clean or replace the filter element
				because of filter element clogged	

Phenomenon		Possible Cause	How to check	Result	Remedy
4. Combustion stops	Misfire lamp is lit.	Absorbing air into fuel lines	Check looseness of each joint	If any joint is loose, air is absorbed	Fasten joints more tightly
during operation.		from joints		into fuel lines from loose joint	
		Insufficient pumping of fuel	Check if air intake of tank cap is	If air intake of tank cap is clogged,	Clean air intake of tank cap
			clogged with dust	fuel flow is insufficient by vacuum	
				forming in fuel tank	
		Shortage of light detected by	Take flame monitor out, and then	If lens of flame monitor is dirty, it	Wipe lens of flame monitor with
		flame monitor	check clarity of its lens	detects a little light	soft cloth
			of human cone and years	flama monitor detects a little of light	Clean burner cone and whiri vane
		Elama monitor connector is	Plug flame monitor connector (CN	If it works normally flame monitor	Plug connector (CN 11) firmly
		loose connection	11) again and then turn on	connector fails on contact	r lug connector (CIV II) mining
		Failure of flame monitor	Unplug flame monitor connector (CN	If resistance doesn't change, flame	Replace flame monitor
			11), and then check transition of	monitor fails	I The second sec
			resistance by changing quantity of		
			light into flame monitor		
		Nozzle clogged	Replace nozzle	If it works normally, nozzle was	Replace nozzle
		Filter element clogged	Check clarity of filter element	If filter is dirty, fuel flow decreases	Clean or replace the filter element
				because of clogged filter element	
5. Smell of fuel comes		Quantity of combustion air is	Check gate opening of combustion air	If opening is too extensive, it burns	Decrease gate opening of
out.		too much	inlet	imperfectly	combustion air inlet.
					Normal scale:
					MPX5 - 2.5
		Nozzle clogged	Replace nozzle	If it works normally, nozzle is	Replace nozzle
		Filter element clogged	Check clarity of filter element	If filter is dirty, fuel flow decreases	Clean or replace the filter element
				because of clogged filter element	
		Incorrect nozzle	Check makers imprint of the nozzle if	If makers imprint is incorrect, the	Replace incorrect nozzle for
			it is correct.	nozzle is incorrect	correct one
			Mark: 0.4USgal/h 80° H		

Phenomenon	Possible Cause	How to check	Result	Remedy
6. Smoke comes out.	Shortage of combustion air	Check extent of combustion air inlet opening	If combustion air inlet is too small, it burns in short of Oxygen	Extend combustion air inlet opening. Normal scale: MPX5 - 2.5 MPX1 - 4.5
	Decrease of airflow from fan motor	Check if fan is dusty	If fan is dusty, it is short of air	Clean fan
	Decrease revolutions of the fan motor	Measure voltage at power source connector	If voltage at power source is lower than standard, combustion air is decreased because of low voltage	Check voltage
	(Power source voltage is insufficient)	Standard: MPX5 - AC120V MPX1 - AC230V		
	Nozzle clogged	Replace nozzle	If it works normally, nozzle was	Replace nozzle
	Using at high altitude area (Low oxygen concentration)	Know the altitude if using at lower than the altitude of 1000m(3000ft)	If using at higher than the altitude of 1000m(3000ft), heater burns imperfectly because of shortage of oxygen	Extend combustion air inlet opening. Normal scale: MPX5 - 2.5 MPX1 - 4.5
	Incorrect nozzle	Check makers imprint of the nozzle if it is correct. Mark: 0.4USgal/h 80° H(danfoss)	If makers imprint is incorrect, the nozzle is incorrect	Replace incorrect nozzle for correct one
7. Combustion is not stable.	Loose joints in fuel line	Check looseness of each joint	If any joints are loose, air is absorbed into fuel lines from loose joint	Fasten joints more tightly
8. Fuel leaks.	Loose joints in fuel line	Check looseness of each joint	If any joint is loose, fuel is leaking	Fasten joints more tightly
	Failure of drain packing	Remove drain bolt after removing fuel from fuel tank, and then check whether packing isn't corrupted	Fuel leaks because of breach of packing	Replace drain packing
	Quantity of fuel in the fuel tank is too much	Check the fuel level	Fuel overflows because quantity of fuel in the fuel tank is too much	Decrease quantity of fuel in fuel tank

Phenomenon		Possible Cause	How to check	Result	Remedy
9. Fuse blows out	When the plug is put	Short circuit of transformer coil	Unplug transformer connector (CN 7)	If either of the values is 0Ω ,	Replace a transformer
	into the outlet.		from burner controller, then measure	transformer is short-circuited	
			coil resistance values of two leads		
			Ston doud		
			MPX5 (white-red) - 2300		
			(numle-numle) - 6 30		
			MPX1 (white-red) - $1.85k\Omega$		
			(burble-burble) - 6.322 • Without tester		
			Unplug transformer connector (CN 7)	If fuse doesn't blow out transformer	
			from burner controller, then put plug	is short-circuited	
			into AC outlet	is short-encured	
		Short circuit of surge absorber	Gauge resistance at surge absorber	If resistance value is 0Ω , surge	Replace burner controller
		(SA1)	(SA1)	absorber is short-circuited	-
		Short circuit of pre-heater	Unplug transformer connector , then	If resistance value is 0Ω , pre-heater	Replace pre-heater
			measure coil resistance values	is short-circuited	
			MPX5 - about 735Ω		
			MPX1 - about 2700Ω		
	When the switch is	Short circuit of fan motor coil	Unplug fan connector (CN 3) from	If resistance value is 0Ω , fan coil is	Replace fan motor
	turned on.		burner controller, then measure	short-circuited	
			resistance between terminals		
		Short circuit of igniter	Unplug igniter connector(CN 4) from	If resistance value is 0Ω , primary	Replace igniter
			burner controller, then measure	side of igniter is short-circuited	
			resistance between terminals	6	
			• Without tester		
			Unplug igniter connector (CN 4), and	If fuse doesn't blow out, igniter is	
			then start operation	short-circuited	
		Short circuit of solenoid valve	Unplug transformer connector , then	If resistance value is 0Ω , solenoid	Replace solenoid valve
			measure coil resistance values	valve is short-circuited	
			MPX5 - about $1.8k\Omega$		
		Short aircuit of fuel nump agil	MPA1 - about 4.782	If registenes value is 00 fuel nump	Paplace fuel nump
	About 5 seconds	Short circuit of fuer pump con	from hurner controller, then measure	coil is short circuited	Replace fuel pump
	after turning on		resistance between terminals	con is short-circuited	
			Without tester		
			Unplug fuel pump connector (CN 6).	If fuse doesn't blow out. pump coil	
			then turn on	is short-circuited	
	About 20~30 seconds	Short circuit of Blower motor	Unplug blower motor connector (CN	If resistance value is 0Ω , blower	Replace blower motor
	after turning on		5) from burner controller, then	motor is short-circuited	
			measure resistance between		
			terminals(4-5PIN)		

7 Standard resistance & Standard Voltage

★ Standard resistance of functional parts

Parte	Connector No		Load	Condition	Resistance		Momo		
Faits	Connec		Leau	Condition	MPX5	MPX1	Memo		
Operating Switch		1-2DIN	Pod-Pod	On	0	Ω			
Operating Switch	CNIQ		Iteu-Iteu	Off	X	Ω			
change over Switch	GINO		White White	On	0	Ω			
change-over Switch		4-3F IN	vvrile-vvrile	Off	X	Ω			
Overheat Protection			Pod Pod	not in working	0	Ω			
Overneal FIDIECTION	CN13		Red-Red	in working	X	Ω			
Tip over Switch	CIVIS		Plack Plack	not in working	0	Ω	Operation angle: $50 - 80^{\circ}$		
rip-over Switch		3-41 IN	DIACK-DIACK	in working	X	Ω	Operation angle: 50 60		
Elama Monitor		11.1	White-White	dark	about	DC5V			
			(Red Line)	light	DC1.2V a	and under			
Transformer	CN7		Red-White	input	about 230Ω	about 1.85kΩ			
Transformer			Purple-Purple	output	about 6.3Ω	about 6.3Ω			
lanitar	CN4		<u>CNI4</u>		Black-Black (thin)	input	-	-	
igniter			Black-Black (bold)	output	about 4kΩ	about 2.8kΩ			
Fuel Pump		2-4PIN	Blue-Blue	-	about 89Ω	about 395Ω			
(Pump coll)	ONIC								
Fuel Pump	CN6				about 7000	about 2.25 k O			
		1-3PIN	yellow-yellow	-	about 70002	about 3.25 K Ω			
valve)			Black Rod	High	about 200	about 1250			
Fan Motor	CN3	1-2FIN	Black-Reu Black Blue	Low	about 2002	about 12502	Normal scale 2.5 (MPX5) Normal scale 4.5 (MPX1)		
Blower Motor			Black-Black	LOW	about 2002				
Eucl pro-bostor	CN5		White-Blue	in working	about 7350	about 27000			
i dei pie-nealei		1-3F IIN	White-Dide	not in working			$20+5^{\circ}$ off		
Thermostat for pre-heater	*	1	Blue-Blue	in working		22			
			Red-Red	in working		- <u></u>			
Solenoid Valve	CN	110	(MPX5) yellow-yellow (MPX1)	-	about1.8kΩ	about4.7 k Ω			

*1 Attached to pre-heater

★Input &Output of Burner Control

Porte	Connector NLo		Lood	Condition	Volt	tage	Mama
Fails	Connec		Leau	Condition	MPX5	MPX1	Mento
Power Cable	CN1		Black - White (MPX5) Brown - Light Blue (MPX1)	-	AC 120V (±10%)	AC 230V (±10%)	
Transformor		NI7	Red - White	input	AC 120V (±10%)	AC 230V (±10%)	
Transformer	C	IN /	Purple - Purple	output	about /	AC 15V	
Igniter	CN4		Black - Black (thin)	input	AC 120V (±10%)	AC 230V (±10%)	
Fuel Pump (Pump coil)		2-4PIN	Blue-Blue	-	AC 60-96V	AC 115-184V	*1
Fuel Pump (Switching solenoid valve)	CN6	1-3PIN	yellow-yellow	-	AC 120V (±10%)	AC 230V (±10%)	
Fon Motor	CN3	1-2PIN	Black-Red	High	AC 120V (±10%)	AC 230V (±10%)	
		1-3PIN	Black-Blue	Low	AC 120V (±10%)	AC 230V (±10%)	
Blower Motor		4-5PIN	Black-Black	-	AC 120V (±10%)	AC 230V (±10%)	
Fuel pre-heater	CIND	1-3PIN	White-Blue	in working	AC 120V (±10%)	AC 230V (±10%)	
Solenoid Valve	Cl	N10	Red-Red (MPX5) yellow-yellow (MPX1)	-	about AC 100V	about AC115V	*2

*1/*2 Output voltages vary according to mesuring instrument because they are half-wave/fullwave rectification

8 Check & Repair

Figure 1	Removing a burner cover	16
Figure 2	Removing a burner unit	16
Figure 3	Mesuring resistance	17
Figure 4	Mesuring voltage	17
Figure 5	Checking a surge absorber (SA1)	17
Figure 6	Replacing a fuse	18
Figure 7	Checking a filter element	18
Figure 8	Checking a fuel tank	19
Figure 9	Checking a fuel pump	19
Figure 10	Positioning a electrode	20
Figure 11	Cleaning a frame monitor	20
Figure 12	Checking a burner cone and whirl vane	21
Figure 13	Adjusting an air inlet opening of fan motor	22
Figure 14	Checking a pre-heater	23

Figure 1 Removing a burner cover

Unscrew two screws and take burner cover off



Figure 2 Removing a burner unit

Unscrew three nuts as below and take the burner unit off



Figure 3 Mesuring resistance

- ① Unplug an intended connector from burner controller
- ⁽²⁾ Turn on the multimeter and set multimeter range
- ③ Insert the lead head of multimeter to connector [lead wire side] and measure resistance



Figure 4 Mesuring voltage

- ① Operate the heater
- ⁽²⁾ Turn on the multimeter and set AC voltage range (partially direct current range)
- ③ Insert the lead head of multimeter to connector and measure voltage



Observation

- ※ Be sure to set resistor at proper range
- * Be careful not to insert the lead head of resistor strongly since damage in connector may occur

Figure 5 Checking a surge absorber (SA1)

Take out the burner controller, and point the lead head at solder part of SA1





Figure 6 Replacing a fuse

Be sure to unplug the power plug then open the fuse cap and Check whether fuse is blown out



Figure 7 Checking a filter element

Check whether or not the filter element is dirt or foul In case the filter element is dirty, replace it with a new one

- **1** Remove the suction pipe from the fuel tank.
- 2 If the filter is dirty, replace it with a new one.
- **3** Return the suction pipe to the fuel tank and firmly secure.



Figure 8 Checking a fuel tank

- **1** Remove the fuel cap and insert a suction pump into the tank.
- 2 Remove as much fuel as possible (with the suction pump). Be sure that the fuel being removed is put only into a can or other container approved in your area for holding flamable liquids such as kerosene and Fuel-Oil no heavier than No.2 (Diesel)
- **3** Tighten the fuel cap firmly.
- 4 Prepare an empty container of about 3 liters (0.7gallons) capacity: to hold kerosene and water remaining in the fuel tank, place the container under the drain bolt (of the fuel tank).
- **5** Next, use a 24mm wrench to remove the drain bolt and tilt the fuel tank until the fuel is completely drained out of the tank. (At the same time, be careful not to lose the drain bolt packing.)
- 6 Restore the drain bolt packing and tighten the drain bolt firmly so that fuel can not leak out (of the fuel tank).

- 7 Wipe off kerosene or water spilled over the tank and the surrounding area.
- 8 Be sure to dispose of in a safe manner as approved in your local area the kerosene, etc, placed in the empty container and the materials used to clean up any spilled kerosene, etc. Safely clean and/or dispose of the empty container as also approved in your local area.



Figure 9 Checking a fuel pump

Take out a fuel outlet line then check whether or not fuel comes out CAUTION: Fuel will squirt cheerfully



Figure 10 Positioning a electrode

Take out a burner and check each clearance as below



Figure 11 Cleaning a frame monitor

Observations

- When removing the flame monitor, hold it by its main assembly; do not pull out the cord.
- **1** Remove the burner cover and pull out the flame monitor, and check whether or not its lens is dirty/foul.
- 2 If the lens is dirty/foul, clean the surface of the lens with a soft cotton swab or cloth until it is clear. Do not use any cleansers of any type, e. g., glass cleaner, to clean the lens.
- **3** Replace the flame monitor. Then securely replace the burner cover using the provided screws.



Figure 12 Checking a burner cone and whirl vane

Take out a burner and check whether or not burner cone and whirl vane are dirt or not. In case the burner cone and/or whirl vane is dirty, clean it(them) with cloth or brush. Infrequently abrasive cleanser may be required

CAUTION

When cleaning, be sure not to get soot or dust to adhere to the nozzle. It may cause nozzle clogged or abnormal spray



Figure 13 Adjusting an air inlet opening of fan motor

Unscrew a decorative screw and then extend/narrow an air inlet opening. Also trial operation is required after each adjustment. Be sure to repeat adjustment until following symptoms are identified.

- · Heater ignites within one second after pump starts to operate
- There is no dark smoke
- White smoke extinguishes within two seconds after ignition
- Flame bounces out from the disk
- Smell of fuel clear within ten seconds after ignition



Observation

When heater is used above 1,000m(3,000ft) sea level, adjust air inlet on fan motor for better combustion

Figure 14 Checking a pre-heater

①Unplug the connector of pre-heater

(2)Measure resistance of the pre-heater between A and B. (see below graphic illustration) Standard resistance: $735\,\Omega$



Graphic illustration

